

QUICK START GUIDE

IT TAKES A BIT OF PRACTICE TO FOLD AND UNFOLD QUICKLY AND EASILY. DON'T WORRY IF IT FEELS AWKWARD THE FIRST FEW TIMES; YOU'LL GET THE HANG OF IT SOON. WITH A BIT OF EXPERIENCE, YOU CAN FULLY FOLD OR UNFOLD THE BIKE WITHIN SECONDS.

FOLDING

STEP 1 • The Rear Wheel

You always stand on the left side of the folding bike, which is the side with the display. Hold the handlebars with your left hand and the back of the saddle with your right hand.

Place your right foot on the luggage rack and keep the rear wheel on the ground while pulling the saddle up. Then, with your foot still on the luggage rack, push the rear wheel under the folding bike.

NOTE: The wheels will scissor when folding. Ensure the front wheel is to the left of the rear wheel (steering to the right) for the most compact size.

STEP 2 • The Saddle

Open the seat post clamp and lower the saddle. This automatically locks the rear wheel in the folded position.

STEP 3 • The Handlebars

Fold the handlebars by pushing the metal pin up of the stem clamp with your left hand and simultaneously pushing the stem clamp off with your right hand. With the clamp open, you can easily fold the handlebars down.

WATCH THE VIDEO HERE:



UNFOLDING

STEP 1 • The Handlebars

You also stand on the left side of the folding bike when unfolding. Fold the handlebars up and clamp them securely.

STEP 2 • The Saddle

Pull the saddle up to the desired height and clamp it securely.

STEP 3 • The Rear Wheel

Hold the handlebars with your left hand and the back of the saddle with your right hand.

Now, place your right foot on the rear wheel axle. Keep the front wheel on the ground while pushing the rear wheel back under the bike with your foot. Give the rear wheel some space by slightly lifting the bike by the saddle.

NOTE: Never pull the saddle higher than the maximum height indicated on the seat post.

NOTE: WHEN UNFOLDING, THE CHAIN GOES FROM A RELAXED TO A TENSE STATE. ALWAYS DO THIS CAREFULLY: THE CHAIN NEEDS SOME TIME AND SPACE TO PROPERLY ENGAGE THE TEETH OF THE GEARS.

Make a rolling motion with the bike during the final part of unfolding the rear wheel, as the chain tightens.

If you notice the chain is already fully tensioned while the bike is not fully unfolded, and the chain does not move when you roll the wheels, **the chain is not properly on the rear sprocket**. This can usually be fixed by folding the rear wheel back a bit and then slowly unfolding it again while rolling the bike back and forth. You will hear a few clicks and notice the chain is back in the correct position.

The chain is properly positioned when it moves along with the wheels (and thus the gears). Only when the chain is properly positioned, push through to fully unfold the bike.

THE DISPLAY

Turn on the display by holding the power button on the bottom right of the display for 2 seconds.



Use the + and – buttons to easily switch between the 3, 5, or 9 assistance levels.

NOTE: ALWAYS SET THE ASSISTANCE BACK TO LEVEL 0 OR TURN OFF THE DISPLAY COMPLETELY BEFORE DISMOUNTING.

Visit <https://www.emq.nl/en/manual/> for our manual & instructional video.

ENJOY YOUR NEW EMQ ELECTRIC FOLDING BIKE.